



PANOS 2.25" & 3.50" Emergency Install D00648CI

WHEN REPLACING PCB ASSEMBLIES, PLEASE WEAR AN ESD WRIST STRAP AND CONNECT IT TO ELECTRICAL GROUND

**RISK OF FIRE AND ELECTRICAL SHOCK**

Contact, improper installation, or improper servicing MAY RESULT IN DEATH OR SERIOUS INJURY! Fixture must be installed by a qualified electrician only. Fixture is intended for installation in accordance with the National Electrical Code, local and federal code specifications. Disconnect power at electrical panel before servicing. Retain these instructions for maintenance reference.

**ADVERTENCIA: RIESGO DE INCENDIO O IMPACTO ELÉCTRICO**

Conexión, instalación inapropiada o servicio incorrecto PUEDE CAUSAR MUERTE O HERIDAS GRAVES. La luminaria debe ser instalada únicamente por un eléctrico calificado. La luminaria debe instalarse de acuerdo al Norma eléctrica nacional, al igual que especificaciones locales y normas federales. Se debe desconectar la corriente eléctrica antes de realizar la mantención. Conservar estas instrucciones como referencia para futuras mantenciones.


**ATTENTION: RISQUE D'INCENDIE ET D'ELECTROCUTION**

Une installation, un entretien ou un contact physique non conforme pourraient mener à un DANGER DE MORT OU DE BLESSURE GRAVE! L'appareil doit être installé uniquement par un électricien professionnel qualifié. L'installation doit respecter le code électrique national de même que les lois locales et fédérales en vigueur. Veuillez fermer l'alimentation électrique au panneau principal avant tout entretien. Conserver ces instructions pour référence et tout entretien futur.


**NOTE**

National or municipal codes must be followed regarding fixture installation and set back of thermal insulating material from luminaire. As a guideline, any insulation material must be held away from the luminaire by minimum of 3". Fixtures are not designed for direct contact with thermal insulation.


The following installation instructions relate to the options below




2.25" PANOS Pendant



3.50" PANOS Pendant





2.25" Square  
PANOS Pendant






3.50" Square  
PANOS Pendant

## Remote EM and Driver Box Mounting - Sheetrock Mounting

2.25"/3.50"  
(68mm/100mm)





### Step #2: Screw Mounting Bracket to Blocking




Mounting bracket holes must be 1/8" from ceiling surface

### Step #3: Assemble and Mount Cross Bar Assembly




## Remote EM and Driver Box Mounting

### Step #3




### Step #4



\*Mount EM Button to Canopy


### Step #5

Attach Canopy to Crossbar using Magnets




# Remote EM and Driver Box Mounting - T-Grid Mounting


## Step #1: Driver Box



## Step #2:




## Step #3: Assemble and Mount Cross Bar Assembly




## Remote EM and Driver Box Mounting

### Step #3




### Step #4



\*Mount EM Button to Canopy


### Step #5

Attach Canopy to Crossbar using Magnets




## Remote EM and Driver Box Mounting - Conduit Mount

### Step #1



### Step #2



### Step #3

